

AMR130

Installation Guide

Warnings & Precautions


▲ Danger


To reduce the risk of electric shock, turn off all sources of electrical power to the device during installation or wiring.

▲ Warnings


- Install only by a qualified and trained personnel.
- Follow these instructions accordingly, otherwise damage may occur to the device.
- Follow electrical rules and regulations in the selection of wire materials and gauges.
- Avoid having oil, water, metallic powder or other foreign substances enter the device.
- Avoid using the device in environments where it will be exposed to steam, corrosive, or flammable substances; which can cause short circuits, fires, or explosions.

Front Panel & Terminals





5 Wiring Diagram



Wiring Detail


- 1. Please follow electrical regulations and recommendations in selecting the wire size and type.
- 2. Ensure that the wires are making good contact with the terminals and have been screwed securely.
- 3. Terminals can accept wires with size of no more than 2.0mm².



RS485 Cable Detail

- 1. Use UL2464 shielded twisted stranded copper pair, 24 to 22 AWG recommended.
- 2. Terminate wire ends with cord end or blade lugs.
- Ensure that the wires are screwed tightly to their corresponding terminals.
- Ensure that the positive and negative polarities are correct

RS485 Cable Detail:



8 Parameter View

